



I.3 Depth References

I.3.2 High Water Mark (C)

Device that shows if official high water levels are reached. This can be indicated either by analog (e.g., by signs like a staff gauge) or digital (e.g., by a display).

Graphics	Encoding Instructions	Object Encoding
<p><i>Real World</i></p>  <p><i>IENC Symbolization</i></p> 	<p>A) INFORM can be used to give unformatted text as additional information. For formatted text in an external file, TXTDSC has to be used.</p> <p>B) EU: High Water Marks must be encoded.</p>	<p>Object Encoding</p> <p>Object Class = sistaw(P)</p> <p>(M) catsiw = [15 (high water mark)]</p> <p>(O) INFORM = [additional information, e.g., "I=460cm at gauge Kaub"]</p> <p>(O) NINFOM = (Refer to Section B, General Guidance)</p> <p>(C) TXTDSC = (Refer to letter A)</p> <p>(O) CONDTN = [1 (under construction), 2 (ruined), 3 (under reclamation), 5 (planned construction)]</p> <p>(M) SCAMIN = [EU: 22000; US: 45000]</p> <p>(C) SORDAT = [YYYYMMDD]</p> <p>(C) SORIND = (Refer to Section B, General Guidance)</p>